Manual English

Assembly

1



Take the windbreak out of the carrying bag and open it up until the 2 systems of collapsible poles lie parallel next to each other. Then plug the separate pieces of each pole together so that they are interlocking.

2



Take the open end of each pole and put them into the intend cut-outs in the polyester canvas. Start with the longer pole.

3



Take the 2 supporting cross bars and stick them onto the markings on the frame.

4



Tighten the rope until you reach the desired apex-angle.

5 **on sand** **or** **grass**



To secure the windbreak against drift you have two different choices depending on the ground and surface:
On sand / gravel: Fill up the carrying bag with sand or gravel and use the clip to mound the filled bag onto the backside of the windbreak.
On grass: Use the 3 metal pins as fixations and stick them through the eyes in the canvas and in the eye in the strap on the backside into the ground.

This product is protected by the following intellectual properties: European Community Design Registration: 000210158; BRD Gebrauchsmuster: 202004012082.8

Manual English

Disassembly

1. Remove the fixations against drift (metal pins or filled up carrying bag).
2. Release the tension of the rope until the canvas is lying flat on the ground.
3. Remove the supporting cross bars.
4. Pull the collapsible poles out of the cut-outs in the canvas on one side and then put the poles parallel next to each other.

   Advice:
   It is not necessary to pull neither of the poles completely out of the canvas!

5. Take the two collapsible poles and fold them up simultaneously. Start with the open not covered end of the poles.

Security advice

Depending on the strength of the wind you will experience different kind of wind forces on the windbreak. Please assure that the windbreak is not braking loose while in use or during assembly and disassembly.

Please do not use the windbreak in any misappropriate way.

We will assume no liability for personal injury or property damage due to the cause of drift or improper use of the windbreak.

Max: Fresh breeze, 5 Beaufort, 25 mph

WARNING! Keep the windbreak away from open fire.

This product is protected by the following intellectual properties: European Community Design Registration: 000210158; BRD Gebrauchsmuster: 202004012082.8